

# Les Mills Immersive Fitness

UPDATE GUIDE FOR CUSTOMER – LMP2.0 02/2020

## 1. Preparations:

- Prepare your keyboard and mouse for this action (Use the shown Logitech K400 if you have it).  
Note: The "Command" key is labelled with the windows logo on this keyboard.








- Put the Content Stick, which you received from LesMills, directly into the Mac Mini or the front USB provided.





- Go in front of the screen and ensure a good view on the projection.


## 2. Update Procedure

- Press  +  (Command+ESC together) to exit full screen mode.
- Press  +  (Command+Comma together) to open the Preferences dialog. Alternatively, you can select Preferences at the menu bar.
- Type in the studio password. You'll find this on your handover protocol.




This is the Preference window which will be opened by  + 

- Select the "Content" tab.
- Remember the number of parts you have (XPT). This is the same as your number of installed video projectors.
- Click "Update".




A file dialog will pop up.

1. Select the "Stick TXX..." at the left side.
2. Select the "Content Update Folder".  
Make sure the number XPT matches your amount of parts.
3. Press Open.
4. The system will start copying the files.




After copying the system will show the latest installed Trip as Version.



- Close the Preferences window.
- Make sure it displays „Les Mills Player“ at the menu bar. If not, click its icon at the Dock.
- Drag the mouse to the menu bar.
- Click on "View".
- Click on "Launch Immersive Player".

Alternative Shortcut:



The iPad should now display the updated content on the movie library, if not please use the "Help" button to request support, by using the ticket system.